

# Polariser and Analyser

## Polariser:

optic used to polarise the light

**Nicol Prism:** O-Ray is eliminated using concept of Total Internal Reflection and only E-ray is perfectly polarised and transmitted

**Polaroids:** O-Ray is eliminated using “selective absorption”

**Tourmaline Crystal** and doped **PVA** is also used for Dichroism

## Analyser:


Polariser used to detect or analyse polarised light

# Huygen's Theory of Double Refraction

“Light Energy propagates in terms of wavefront”


## Assumptions:

1. when beam of light strikes a double refacting crystal each point on the refracting surface acts as a source for two secondary wavefronts, which spread out in to the crystal
2. One wavefront obeys the ordinary laws of refraction which travels with the same speed in all the directions. Hence corresponding wave surface is spheroid and called as O-wavefront
3. Second wave front travels with different velocities in different directions. Hence wave surface is ellipsoid called E-wavefront. They do not obey Snell's law
4. The rays corresponding to the two wavefronts merge along the optic axis. The O- and E-Wavefront velocities are equal along the optic axis.



Negative Crystal

E-Wavefront  
O-Wavefront




Positive Crystal

5. The direction of propagation of E- Wavefront depends on direction of optic axis relative to the refractive surfaces


## The wavefronts of E and O rays for different orientations of optic axis

For Negative Crystals



# The wavefronts of E and O rays for different orientations of optic axis

## For Positive Crystals



# Theory of Circularly And Elliptically Polarized Light

E ray and O ray vibrate in perpendicular directions with phase difference  $\Phi$






Then

$$x = a \sin \omega t \quad y = b \sin(\omega t + \phi)$$

Superposition of E- Ray and O-Ray results

$$\frac{x^2}{a^2} + \frac{y^2}{b^2} - 2 \frac{xy}{ab} \cos \phi = \sin^2 \phi$$

## Equation of an Ellipse

$\Phi$	$0^\circ$ $360^\circ$	$180^\circ-270^\circ$ $0^\circ-90^\circ$	$270^\circ$ $90^\circ$	$270^\circ-360^\circ$ $90^\circ-180^\circ$	$180^\circ$
					

<b><math>\phi</math></b>	<b>Resulting eqn</b>	<b>Resulting vibration</b>	<b>Remark</b>
$0^\circ, 360^\circ$	$y = \frac{b}{a}x$	Straight line	If two PPL is superimposed with zero phase difference then resulting vibration is PPL
$180^\circ$	$y = -\frac{b}{a}x$	Straight line	If two PPL is superimposed with zero phase difference hen resulting vibration is PPL
$90^\circ, 270^\circ$ $a \neq b$	$\frac{x^2}{a^2} + \frac{y^2}{b^2} = 1$	Ellipse	If two PPLs with unequal amplitudes are superimposed with a phase difference of $90^\circ, 270^\circ$ , the resulting vibration is EPL
$90^\circ, 270^\circ$ $a = b$	$x^2 + y^2 = a^2$	Circle	If two PPLs with equal amplitudes are superimposed with a phase difference of $90^\circ, 270^\circ$ , the resulting vibration is CPL

## Retardation Plates

**When a light falls normally on a doubly refracting uniaxial crystal plate cut with optic axis parallel to the refracting surfaces, a phase difference between the O-ray and E-Ray is introduced. Then the crystal is called as Retardation Plate**

**The path difference between the two rays is given by**

$$\Phi = (\mu_o - \mu_e)t$$

**$\mu_o$  - Refractive index of O-Ray**


**$\mu_e$  - Refractive index of E-Ray**

**t - thickness of the plate**

**Ex: Quarter Wave Plate, Half Wave Plate**

# Quarter Wave Plate

It is doubly refracting uniaxial crystal plate that introduces a phase difference of  $\pi/2$  or path difference of  $\lambda/4$  between the O-Vibrations and E-vibrations, when light normally incident on it



**For Negative Crystal**

$$t = \frac{\lambda}{4(\mu_o - \mu_e)}$$

**For Positive Crystal**

$$t = \frac{\lambda}{4(\mu_e - \mu_o)}$$

Ex: Mica, Quartz

**Converts PPL in to CPL (or EPL) and conversely  
it also converts CPL (or EPL) in to PPL**

# Half Wave Plate

It is doubly refracting uniaxial crystal plate that introduces a phase difference of  $\pi$  or path difference of  $\lambda/2$  between the O-Vibrations and E-vibrations, when light normally incident on it

For Negative Crystal

$$t = \frac{\lambda}{2(\mu_o - \mu_e)}$$

For Positive Crystal

$$t = \frac{\lambda}{2(\mu_e - \mu_o)}$$


Made from doubly refracting uniaxial crystal, cut with refracting faces parallel to optic axes

Used to alter the direction of vibration of the linearly polarized light by angle  $2\theta$

$\theta$ --- angle between incident vibration and the optic axis

# Detection

Allow the light to pass through the analyser



# Application

Polarising Sunglass- cuts the glare of light



# Optical Activity


Certain Materials have an ability to rotate the plane of vibration of PPL

Ex: Sugar solution, Turpentine, Liquid Crystals, Tartaric acid, Camphor, Cholestrol


Angle of rotation ( $\theta$ ) depends on

1. Concentration (c)
2. Length of the Cell (l)
3. Specific Rotation (S)

$$\theta = Slc$$





# Saccharimeter



Instrument for measuring the concentration of sugar solutions


# Liquid Crystal Display

- System of two crossed polarisers do not transmit the light
- Place optically active Liquid crystals between polarisers
- LC's rotate the PPL by 90°
- Now pass the UPL through the polariser, it will allow vertical vibrations
- LC rotate the vertical vibrations into horizontal vibrations
- these produced horizontal vibrations passed through the analyser
- keep mirror in front of analyser, so that horizontal vibrations reflect back to L.C. through the analyser, rotate again and comes out through the polariser
- System appears bright
- now apply small voltage to L.C., it loses optical activity, vertical components not rotated in to horizontal, so Ppl is blocked at the analyser
- System appears Dark




Using This Principle Seven segment displays were constructed

Similarly Combination of R.G.B LC's used in Color displays





# 3-D Movies

- ✓ Shot twice through two lenses kept side by side
- ✓ These two movies are projected on the screen through two projectors mounted with two polarisers, vertical and horizontal
- ✓ Viewer looks movie with a special goggle mounted with two polarisers horizontal for one eye and vertical from another
- ✓ Thus one eye sees only horizontally polarised movie and another see only vertically polarised movie
- ✓ Our brain mixes these two pictures and thus 3D stereo screen version is produced



# Photo-Elasticity

Due to force, defects or stressed Zones present in the components  
These can be made visualised by polarisers  
i.e. some material may become double refracting in stressed zone



# Thank you

